## Signal distributor





## Description

This product allows connection, from one signal input auxiliairy level, up to 20 signal sockets, each one totally independent from others. The use of this product is recommended in specific application, you need to broadcast audio signal from sound system towards other equipment such as recording for media, radio, TV, etc.


## CONNECTION AND ADJUSTMENT INSTRUCTION


1.- Connect audio signal from sound system to signal input (DIN).

2.-Activation of mains switch "ON".

**3.-** Adjust potentiometer of volume from the back, in order that with modulation at adjusted level, the green led lights "MOD" intermittently.

Signal outputs (1 - 10)	
- Signal:	Balanced.
- Level:	0 dBm.
- Impedance:	600Ω.
- Connector:	XLR.
Signal outputs (11 - 20)	
- Signal:	Unbalanced.
- Level:	-10 dBm.
- Impedance:	600Ω.
- Connector:	Jack 6 mm.
- Sensitivity:	100 mV.
- Power supply:	230 VAC
- Weight:	6.5 Kg.
- Dimensions:	428x330x100.







EQUIPOS Y SISTEMAS MEGAFONÍA/INTERCOM • PUBLIC ADDRESS SYSTEMS UNIÓN DESARROLLOS ELECTRÓNICOS

Tel.: +34 934 772 854 / +34 609 914 787 • ude@udeaudio.com • BARCELONA - SPAIN

www.udeaudio.com

rev.1 610.118A 1 / 1

UDE se reserva el derecho de variar las características técnicas de sus productos sin previo aviso • UDE reserves the right to modify the technical characteristics of its products without previous notice