


## Centrale ID-200 USE



- |  |                               |  |
|--|-------------------------------|--|
| <b>1</b> Alphanumeric keypad from 0 to 9 | <b>5</b> VALIDATION button    | <b>9</b> DISPLAY                                     |
| <b>2</b> INTERCOM button                 | <b>6</b> CANCEL button        | <b>10</b> XLR CONNECTOR (5c) FOR EXTERNAL MICROPHONE |
| <b>3</b> SOUND button                    | <b>7</b> FUNCTION button      | <b>11</b> SPEAKER                                    |
| <b>4</b> CLEAR button                    | <b>8</b> TALK / LISTEN button | <b>12</b> MICROPHONE                                 |

### IMPORTANT

If the system incorporates the CM-23 microphone options, the function of speech is performed by the microphone talk button.

Connecting the CM-23 microphone **10** replaces the internal microphone **12** of the central talk button.



# SUMMARY USE

CONFIGURATION ..... Pag. 3

HOLD DISPLAY ..... Pag. 3

INCOMING CALLS VIEW ..... Pag. 4

CALL ANSWERING ..... Pag. 4

DIRECT CALL TO ZONE ..... Pag. 5

CALL BY NAME ZONE SELECTION ..... Pag. 6

GENERAL CALL TO ALL ZONES ..... Pag. 7

tone SET / CALL VOLUME / SYSTEM TEST ..... Pag. 7

CALL DIVERSION TO ANOTHER ZONE DESK ..... Pag. 8

CALL DIVERSION TO TELEPHONE ..... Pag. 9

CALL RESPONSE BY TELEPHONE ..... Pag. 10

# INTERCOM-200 System

## CONFIGURATION

By the **ID-200 UdeConf** software you can change the following:

**Name of each area:**

By default are called zone 1, zone 2, ... But we can give the name we want to each zone by the letters and numbers, with a maximum of 19 characters.

**Extension number for each zone:**

This is the identification number of the zone, it can have up to four digits.

**Assigned desk to each zone:**


By default with a single desk, all zones will be assigned to a no. 1 desk. **Floor:**

Each zone can be assigned to the floor you want. This affects mainly the response by telephone.

**Sound by phone:**


You can choose the name for each room (sound) and the floor to give the message through the telephone interface: Room, Area, Gate (in the menu of available words).

## HOLD DISPLAY




In standby, the screen shows the software version and the number of desk.


## INCOMING CALLS VIEW



The call appears on the screen, indicating the extension number assigned to the calling area.  
**Example** of a call to extension 101



And then, it shows the name assigned to the extension



Then join the list of incoming calls on a first come.  
The call appears on the screen, indicating the extension number and then the name assigned.  
**Example:**      join call from  
                         Extension 116 (Room 16)

# INTERCOM-200 System

## CALL ANSWERING

```
Llamada:
> zona1
  zona16
```

To respond in the order of the list, simply press the intercom button **A** / **D** **ENTER**

To select the call in a different order on arrival, move the pointer down or up using the up / down buttons

**7** Up

**\*** Down

Then confirm by pressing **D** **ENTER**

```
Comunic. ext.. 101
zona1
Volumenescucha 4
```

To speak press / **CM-23** **P** Release to listen

If passing 30 seconds the button isn't activate, the call is automatically canceled.

**Listening volume:** You can change the listening level by buttons 1-7 (in intercom)

```
Llamada:
> zona16
```

To end the call press **CANCEL**


You return to the list of unanswered calls

```
ID-200
(v_)
Pupitre1 (1)
```



If there is not any unanswered call, the screen returns to standby mode

# INTERCOM-200 System

## DIRECT CALL TO ZONE




To select directly a zone, press the EXTENSION number on the alphanumeric keypad.



Press the corresponding number to the extension area you want to make the call. The screen displays the name assigned to the area.


Then, validate pressing ENTER



To speak press / Release to listen

If for 30 seconds the button isn't activated, the call is automatically canceled.

**Listening volume:** You can change the listening level by buttons 1-7 (in intercom)



To end the call press CANCEL

You return to the list of unanswered calls.

# INTERCOM-200 System

## CALL BY NAME ZONE SELECTION

```
ID-200
(v_)
Pupitre1 (1)
```

Open the name menu assigned to each zone based



```
> zona1
zona2
zona3
zona4
```

Search for the calling area, by moving in the menu the up or down buttons.



```
zona1
zona2
> zona3
zona4
```

Select the name of the area  
**Example: call for Zone 3**

And then, validate pressing



```
Comunic. Ext. 103
zona3
Volumenescucha 4
```

To speak press



Release to listen

If for 30 seconds the button isn't activated, the call is automatically canceled.

**Listening volume:** You can change the listening level by buttons 1-7 (in intercom)

```
ID-200
(v_)
Pupitre1 (1)
```


To end the call press



You will return to the list of unanswered calls.

# INTERCOM-200 System

## GENERAL CALL TO ALL ZONE



Press the button To do this operation it requires an additional amplifier


To speak press Release to listen

If for 30 seconds the button isn't activated, the call is automatically canceled.

To end the call press

You will return to the list of unanswered calls

## TONE SET / CALL VOLUME / SYSTEM TEST



Press the button

Select the desired setting by pressing

### "Listen volume"

Select the desired setting by pressing the buttons 1-7.

Then, validate pressing

### "Tone volume"

We will listen to the notice of appeal tone

Select the desired setting by pressing the buttons 1-7.

Then, validate pressing

### "System test"

Press the button

Display show the zones modules available

1 - 20 **OK**

21 - 40 **OK**

If a module is not available the screen shows: 40 - 60 **X**

To complete the test press the button

To complete the configuration press the button

The screen returns to standby mode

# INTERCOM-200 System

## CALL DIVERSION TO ANOTHER ZONE DESK

```

ID-200
(v_)
Pupitre1 (1)
    
```

Press the button **C**

```

Seleccionar desvio:
Anular desvio
* Desvio a pupitre
Desvio a telefono
    
```

Select the "Diversion to desk" by **\*** **F**

Then, validate pressing **D** **ENTER**

```

Num. de pupitre
Pupitre:      _2
    
```

We mark on the keyboard the number to the dispatch desk  
**Example: Difference in panel 2**

Then, validate pressing **D** **ENTER**

```

Desviado a pupitre
      2
(C) para anular
desvio
    
```

From now on, the desk is inhibited and all incoming and outgoing calls are shown on the display but will be managed from the phone.

To stop the diversion press **C**

```

Seleccionar desvio:
* Anular desvio
Desvio a pupitre
Desvio a telefono
    
```

Diversion is canceled and the screen returns to standby mode

Then, validate pressing **D** **ENTER**

```


ID-200
(v_)
Pupitre1 (1)
    
```

El desvío queda anulado y aparece la pantalla de espera

# INTERCOM-200 System

## CALL DIVERSION TO TELEPHONE

To do this operation it requires an IW-18 interface.




### IW-18 TELEPHONE INTERFACE

If the IW-18 telephone interface is not incorporated by trying the gap, the display will show




# INTERCOM-200 System




## CALL RESPONSE BY TELEPHONE

To do this operation it requires an IW-18 interface.



A call is received on the SR-200 desk.  
Is indicated on the display, and automatically send to the phone



The wireless phone is ringing

*Ring...Ring*

The person answering the calls pick up the phone

The phone gives the message with data

*CALL  
Floor \_\_\_\_\_  
Room name \_\_\_\_\_*

The person presses the \* button on the phone and speak with the chamber. Finally hangs the phone