

AP-760

Espherical pendant speaker



Hanging spherical projector ideal for installation in rooms with high ceilings.

Provides 360° acoustic dispersion for clear sound.

High performance for both speech and music.





Technical characteristics

Model	AP-760
Power taps (L100V)	7.5W / 10W / 15W / 20W / 30W / 60W
Power taps (L70V)	3.75W / 5W / 7.5W / 10W / 15W / 30W
SPL	102dB
Speaker	6"
Frequency response	100Hz - 13KHz
Finish	White ABS
Dimensions	385*385*305mm
Installation	By fastening hook
Weight	3.4Kg


Power selection

	L100V	L70V
White	7.5W	3.75W
Red	10W	5W
Yellow	15W	7.5W
Brown	20W	10W
Blue	30W	15W
Green	60W	30W
Black	Common	Common



Installation

- 1 Drilling a Ø5mm hole in the ceiling
- 2 In an area close to the hole, install a 10mm hook.
- 3 Connect the three hooks of the speaker with the hook installed in the ceiling.
- 4 Insert the wiring through the hole.



EQUIPOS Y SISTEMAS MEGAFONÍA/INTERCOM • PUBLIC ADDRESS SYSTEMS

UNIÓN DESARROLLOS ELECTRÓNICOS

Tel.: +34 934 772 854 / +34 609 914 787 • ude@udeaudio.com • BARCELONA - SPAIN

www.udeaudio.com

rev.1 | 610.621a | 1 / 2

Safety warnings



**WARNING /
DANGER**
RISK OF ELECTRIC
SHOCK. DO NOT OPEN



TO REDUCE DE RISK OF ELECTRIC SHOCK, DO NOT OPEN THE COVER (OR BACK PART). INTERNAL COMPONENTS CANNOT BE REPLACED OR REPAIRED BY THE USER. CONSULT AUTHORIZED SERVICE PERSONNEL ONLY



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to users.



The exclamation point within an equilateral triangle is intended to alert the user to important operating and maintenance instructions in the literature accompanying the equipment.

CAUTION

Ignoring the caution message may result in minor injury or damage of the product.

Please read this entire manual before use, taking special note of these warnings and safety guidelines.

-Keep this manual in a safe place for future reference.

-This device is intended for indoor use.

-Do not expose this device to rain, water or moisture of any kind.

-Avoid installing the loudspeaker in wind currents that may affect its stability.

-If operating this loudspeaker in a humid environment, ensure that condensation does not occur.

-Do not expose this apparatus to excessive heat.

-Do not place on or near any heat sources such as fireplaces, cookers, radiators, etc.

-Clean only with a soft, dry cloth. Do not use chemical cleaners, solvents or detergents.